

TECHNICAL BULLETIN

The 9th Edition FireNET Panel can be integrated with the FNV-MP voice evacuation system. FireNET firmware 4.00 is required for the integration to function properly. There is no programming necessary to accomplish the integration process. Please refer to the FireNET Installation and Operation Manual version 1.86 (or higher) for instructions on how to integrate the two panels. The integration of the FireNET Panel with the FNV-MP is UL listed.

<u>Note</u>: FN-DAC or Serial Printer may not be used on the 9th Edition FireNET panel directly, connected to the VoiceNET Master Panel via voice evacuation integration cable (FN-V187)

If you have any questions regarding this matter please contact Technical Support.

Technical Support 1-800-845-6692 Technical Support@hochiki.com

Initial Release: 11/30/09 Revised: 09/13/2010

TB-006 Rev. 1.01